

DEEP SNOW 180 TURBO Air-In MOD

**Install leftover Edge Guard
Rubber over end of Screen**

**MOUNTAIN
PERFORMANCE**

**MUST!
Reinstall Snow Prefilter
MUST**

Cut (or tear) foam off at Base of Filter

