



2011+ Apex Supercharger Modifications for Power Steering

1. Mounted the voltage regulator down below everything, As low as you can get it in the nose.
2. Installed the blower's oil tank in place of the voltage regulator with the same tank brackets, and same length hoses.
3. Move the power steering unit down maybe an inch or so to clear the intercooler.
4. Everything is a real tight snug fit, but works out just fine.