

# **MTN-1000 180HP NYTRO TURBO SETUP**

**Please adjust boost for your altitude.**

**To access the waist gate actuator.**

- 1. remove seat and dog house.**
- 2. remove clevis pin.**
- 3. back off 10mm jam nut (do not turn rod)**
- 4. turn clevis in or out.**
- 5. re-tighten jam nut.**

**1-1 ½ turns in (clockwise) increases boost about 1 PSI**

**1-1 ½ turns out (counter clockwise) decreases boost about 1 PSI**

**Boost Targets for pump gas**

**0-3000/FT 4-5 PSI**

**3000-8000 5-6 PSI**

**8000+ 6-7 PSI**

**Refer to main instruction manual for other important operating instructions. (ie. Fuel, clutching, operating temps, etc.)**

**Do not operate under full boost with water temps above 180F (outlet)**